



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

AK Alpha Railed Dot Mount – MI-AK-ALPHA-RDM / MI-AK-ALPHA-T2M

It is recommended these parts are installed by a qualified gunsmith. Failure to read and follow these instructions will void the warranty of these parts and may result in damage to your firearm or optics

ONLY for use with MI AK Alpha series handguards. Not compatible with other generations of Midwest Industries products or other manufacturer's products

Please be sure to install MI AK Alpha series handguard before starting the steps below. This mount cannot be installed at the same time as installing the handguards

Instructions

1. Please make sure your firearm is unloaded and pointed in a safe direction.
2. Repeat step one
3. Remove all packaged components and get familiar with them.
 - a. Vibratite is included for final step of torquing all fasteners. Do NOT use Loctite.
4. Remove all fasteners and keep track of them, these will be used to reassemble the unit.
5. Find the steel support struts. These are black, have 3 threaded holes and are a couple inches in length.
6. Install steel struts by sliding them in between the heat shield and handguard. The single screw leg extends to the rear of the rifle. Start the provided flat head screws but do not tighten them.
7. Install aluminum side beams with provided hardware to the rear M-LOK slots of the top cover on the handguard. Do not torque the bolts.
8. Slide the optic mount into position between both aluminum support beams. Install the 4 screws into the mount and last 2 screws into the steel support struts.
9. Tighten all bolts to torque specs below
 - a. Torque M-LOK screws to 20inch lbs with locking nuts engaged.
 - b. Torque 6x32 flat heads to 10inch lbs.
10. Thank you for your purchase. Please contact us with any questions!

Installation Video ---

