



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

Benelli M4 Handguard – MI-BENM4-HG

It is recommended these parts are installed by a qualified gunsmith

Midwest Industries is not responsible for parts damaged by not following these instructions. Please read the instructions and get familiar with these parts before proceeding with installation.

Instructions

1. Make sure your shotgun is unloaded and pointed in a safe direction.
2. Repeat step 1.
3. Per your shotguns owner's manual, remove your barrel assembly and plastic handguards.
4. Using a snap ring pliers, remove the snap ring that holds the sling loop in place, then remove the sling loop.
5. Set the rear handguard collar into the stamped cap on your shotgun. Leave gun standing vertical.
6. With the barrel pointed down vertically, set the forward cap into the cast ring on the barrel.
7. While holding the barrel vertically, slide the handguard from the chamber end down onto the forward ring and start the four screws. Do not tighten the screws, leave them finger tight.
8. Slide the barrel assembly down onto the gun, start the screws for the rear retaining cap.
9. Tighten the barrel assembly onto the gun making sure your barrel is fully seated.
10. Tighten all 6 mounting bolts to 20inch lbs.
11. While pulling down on the handguard, install the brass set screws and screw them until they touch.