



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

Beretta 1301 Handguard – MI-1301-HG

It is recommended these parts are installed by a qualified gunsmith

Midwest Industries is not responsible for parts damaged by not following these instructions. Please read the instructions and get familiar with these parts before proceeding with installation.

Instructions

1. Make sure your shotgun is unloaded and pointed in a safe direction.
2. Repeat step 1.
3. Remove the factory 1301 handguard per factory owner's manual. You will need it for step 4.
4. Remove the front tension collar in the factory handguard. To do this, pull the rubber O-ring to the rear and remove, then slide the collar out the front of the handguard.
5. Push the tension collar into the MI front ring. Push the raised boss into the slot, in the front ring. Re-install the O-ring onto the rear of the tension collar.
6. Install the front ring into the handguard. The tension post goes to the front, the O-ring to the rear.
7. Degrease the provided screws. After drying, apply a drop of Vibra-tite to each front ring screw, install and torque evenly to 30inch lbs.
8. Install the MI handguard onto your shotgun.
9. Thank you for supporting USA made products.



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

Beretta 1301 Handguard – MI-1301-HG

It is recommended these parts are installed by a qualified gunsmith

Midwest Industries is not responsible for parts damaged by not following these instructions. Please read the instructions and get familiar with these parts before proceeding with installation.

Instructions

1. Make sure your shotgun is unloaded and pointed in a safe direction.
2. Repeat step 1.
3. Remove the factory 1301 handguard per factory owner's manual. You will need it for step 4.
4. Remove the front tension collar in the factory handguard. To do this, pull the rubber O-ring to the rear and remove, then slide the collar out the front of the handguard.
5. Push the tension collar into the MI front ring. Push the raised boss into the slot, in the front ring. Re-install the O-ring onto the rear of the tension collar.
6. Install the front ring into the handguard. The tension post goes to the front, the O-ring to the rear.
7. Degrease the provided screws. After drying, apply a drop of Vibra-tite to each front ring screw, install and torque evenly to 30inch lbs.
8. Install the MI handguard onto your shotgun.
9. Thank you for supporting USA made products.