



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

www.midwestindustriesinc.com

Smith & Wesson Rail System Installation Instructions

Please read all instructions step-by-step before proceeding to install this product. If instructions are not followed, your warranty is void. If you are not comfortable with this install, please have this product installed by a qualified gunsmith.

****Disclaimer****

THIS IS NOT A HANDGUARD - Midwest Industries Inc. is not liable for any injury because of misuse of our products or the firearm. Please note these are for revolver firearms. User **MUST** wear ear and eye protection when using this product. Both hands must stay clear of cylinder or blast could cause injury. Midwest Industries Inc. is not responsible for misuse of it's accessories. It is the responsibility of the purchaser to ensure that possession and use of this item is in compliance with all relevant federal, state, and municipal laws or statutes. End user is responsible for any ATF requirements.

- 1. Before proceeding, make sure the firearm is pointed in a safe direction, and has a chamber empty. Remove all ammunition from the workspace.**
- 2. Repeat Step 1**
- 3. Remove factory rear sight**
- 4. Separate top and bottom halves of rail system and get familiar with the components**
- 5. Loosely install the top rail piece onto the gun with the provided receiver screws in the bag**
- 6. Install the lower section onto the top section. The short (1/4 long) 6-32 screw goes in the spot above the cylinder rod.**
- 7. Incrementally tighten the set screws to center the handguard on the barrel**
- 8. Do a final snug on all the screws. Do not overtighten and strip the screw heads**
- 9. Enjoy!**

If you have any questions about the install please give us a call at:

262-896-6780