



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

Chiappa Takedown 1886 / 1892 M-LOK Handguard Instructions

MI-C86-HG / MI-C92-HG

It is recommended these parts are installed by a qualified gunsmith

Midwest Industries is not responsible for parts damaged by not following these instructions. Please read the instructions and get familiar with these parts before proceeding with installation. Loss of parts or failure to follow the instructions are not covered by warranty.

Instructions

1. Make sure your rifle is unloaded and pointed in a safe direction. Check chamber and tube.
2. Repeat step 1.
3. Remove the factory tube magazine.
4. Remove the factory handguard.
5. Install the MI handguard by hinging the rear in first, then the front. In some cases, you may have to loosen the front cap screws to get the front to hinge past the front tenon.
6. Tighten the front yoke screws. Tighten these to 15inch lbs.
7. Install the front two provided tenon screws. Tighten these to 15inch lbs.
8. Evenly tighten the brass set screws so that you have an even gap on each side of the barrel when tight. Check the front and rear as you do this.
9. Re-install your mag tube.
10. Thank you for your purchase!



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

Chiappa Takedown 1886 / 1892 M-LOK Handguard Instructions

MI-C86-HG / MI-C92-HG

It is recommended these parts are installed by a qualified gunsmith

Midwest Industries is not responsible for parts damaged by not following these instructions. Please read the instructions and get familiar with these parts before proceeding with installation. Loss of parts or failure to follow the instructions are not covered by warranty.

Instructions

1. Make sure your rifle is unloaded and pointed in a safe direction. Check chamber and tube.
2. Repeat step 1.
3. Remove the factory tube magazine.
4. Remove the factory handguard.
5. Install the MI handguard by hinging the rear in first, then the front. In some cases, you may have to loosen the front cap screws to get the front to hinge past the front tenon.
6. Tighten the front yoke screws. Tighten these to 15inch lbs.
7. Install the front two provided tenon screws. Tighten these to 15inch lbs.
8. Evenly tighten the brass set screws so that you have an even gap on each side of the barrel when tight. Check the front and rear as you do this.
9. Re-install your mag tube.
10. Thank you for your purchase!