



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

Henry Homesteader M-LOK Handguard Instructions

MI-HH

It is recommended these parts are installed by a qualified gunsmith

Midwest Industries is not responsible for parts damaged by not following these instructions. Please read the instructions and get familiar with these parts before proceeding with installation. If you have questions, please contact us via phone or email for assistance.

Instructions

1. Make sure your rifle is unloaded and pointed in a safe direction.
2. Repeat step 1.
3. Remove the factory wood handguard
4. Using the provided wrenches, remove the front mounting block and receiver block from the MI Handguard
5. Install the front mounting block to the rifle using the provided 10-32 socket head cap screw. Torque the bolt to 30-inch lbs.
6. Slide the receiver transition block into the front of the receiver
7. Reinstall the flat head screws into the handguard and torque to 30-inch lbs.
8. Tighten brass set screw until it touches the barrel finger tight (Do NOT overtighten)
9. Your rifle is now ready to use.