



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

Henry Supreme M-LOK Handguard Instructions

MI-HSP

It is recommended these parts are installed by a qualified gunsmith

Midwest Industries is not responsible for parts damaged by not following these instructions. Please read the instructions and get familiar with these parts before proceeding with installation.

Instructions

1. Make sure your rifle is unloaded and pointed in a safe direction. Check chamber and magazine.
2. Repeat step 1.
3. Remove your factory Handguard
4. Slide on the receiver trim block. It will fit into the channel and will be an obvious fit.
5. Install mounting block bolt finger tight. Use Vibra-tite on this screw as well.
6. Tighten the mounting block bolt to 40-inch pounds.
7. Slide the handguard on.
8. Install the 2 rear 8-32x1/4 flat heads into the side of the handguard by the trim ring.
9. Install the 6 handguard attachment screws into the bottom of the handguard and tighten to 10-inch pounds. Use Vibra-tite on these screws.