



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

www.midwestindustriesinc.com

KelTec KSG M-Lok Mount Installation Instructions

MI-KSG-MM

Please read all instructions step-by-step before proceeding to install the handguard.

(If instructions are not followed, your warranty is void. If you are not comfortable with this install please have the KelTec KSG M-Lok Mount installed by a qualified gunsmith.)

Before proceeding, make sure your firearm is pointed in a safe direction, magazine removed and chamber empty. Remove all ammunition and magazines from the workspace.

- 1.) Place safety on safe, cycle the action to the rear and manually inspect the magazine tubes on BOTH sides to ensure the KSG is completely empty, inspect the chamber to make sure it is empty.
- 2.) Return the action to the forward position and locate the rail on the bottom of the pump.
- 3.) Remove cross bolt and slide M-Lok mount onto the factory forearm bottom rail, slide it all the way forward so the threaded holes for the hand stop are at the front of the forearm.
- 4.) Install the KSG M-Lok Mount cross bolt through the mount and torque until mount does not move front to rear.
- 5.) Install the hand stop to the KSG M-Lok Mount with the provided screws, torque screws to 35 inch/pounds.
- 6.) Perform a function check to make sure the firearm is in good working condition and all parts were reinstalled correctly.

Modification or alteration to this part (to include custom coatings) voids all factory warranties.

If you have any questions about the install please give us a call at:
262-896-6780