
KUNA SD M-LOK® HANDGUARD

Installation Instructions

SKU: MI-KUNA-SD8 Fits: Springfield Armory Kuna

READ BEFORE INSTALLATION. Please read all instructions step-by-step before proceeding to install this product. If instructions are not followed, your warranty is void. If you are not comfortable with this install, please have this product installed by a qualified gunsmith.

DISCLAIMER

Midwest Industries Inc. is not liable for any injury because of misuse of our products or the firearm. Midwest Industries Inc. is not responsible for misuse of its accessories. We are not responsible for stripping of screws due to over tightening. It is the responsibility of the purchaser to ensure that possession and use of this item is in compliance with all relevant federal, state, and municipal laws or statutes.

INSTALLATION

1. **Before proceeding, make sure the firearm is UNLOADED and pointed in a SAFE direction. Remove all ammunition from the workspace.**
2. **Repeat Step 1.**
3. Install the provided side spacers all the way to the rear, with the arrow facing the muzzle end of the firearm.
4. Install the short lower spacer with 1/4 inch of the M-LOK® slots showing on each end of the spacer, with the arrow facing the muzzle end.
5. Slide the handguard on and use the provided flat head bolts to attach it to the spacers. Torque the bolts to **20 inch lbs.**

If you have any questions about the install, please give us a call at **262-896-6780**.