



MI-T1-NV

Midwest Industries Non-QD NV Height Mount for Aimpoint T1/T2 Pattern Optics

Installation Instructions

Remove bolts from MI optic mount and install desired red dot with compatible T2 Interface. Torque optic screws to manufacturer recommended specification. Slide MI optic mount onto upper receiver and torque optic mount cross bolts to **40 inch lbs.**

Midwest Industries is NOT responsible for optic or optic mount stripped screws.



MI-T1-NV

Midwest Industries Non-QD NV Height Mount for Aimpoint T1/T2 Pattern Optics

Installation Instructions

Remove bolts from MI optic mount and install desired red dot with compatible T2 Interface. Torque optic screws to manufacturer recommended specification. Slide MI optic mount onto upper receiver and torque optic mount cross bolts to **40 inch lbs.**

Midwest Industries is NOT responsible for optic or optic mount stripped screws.



MI-T1-NV

Midwest Industries Non-QD NV Height Mount for Aimpoint T1/T2 Pattern Optics

Installation Instructions

Remove bolts from MI optic mount and install desired red dot with compatible T2 Interface. Torque optic screws to manufacturer recommended specification. Slide MI optic mount onto upper receiver and torque optic mount cross bolts to **40 inch lbs.**

Midwest Industries is NOT responsible for optic or optic mount stripped screws.



MI-T1-NV

Midwest Industries Non-QD NV Height Mount for Aimpoint T1/T2 Pattern Optics

Installation Instructions

Remove bolts from MI optic mount and install desired red dot with compatible T2 Interface. Torque optic screws to manufacturer recommended specification. Slide MI optic mount onto upper receiver and torque optic mount cross bolts to **40 inch lbs.**

Midwest Industries is NOT responsible for optic or optic mount stripped screws.