



W292S4498 Hillside Rd. Waukesha, WI 53189  
262-896-6780 Fax 262-896-6756  
[www.midwestindustriesinc.com](http://www.midwestindustriesinc.com)

## Rossi 95 Handguard Installation Instructions

Compatible with Rossi 95 firearms

**It is recommended this product is installed by a qualified gunsmith. Failure to follow instructions will VOID warranty. If you have any questions, please contact us and we will be able to assist.**

1. Make sure your rifle is unloaded and pointed in a safe direction
2. Repeat step 1
3. Remove the factory handguard cap and handguard. Reassemble without factory handguard.
4. Slide the MI handguard onto your rifle and seat the location tangs into the recess of the receiver
5. Apply a drop of Vibra-tite to all the installation screws
6. Start the front hold down screws in the handguard. Do not torque
7. Install the 2 brass set screws in the front. Screw these in until they contact the barrel. While tightening the front screws, make sure the handguard is centered with the barrel.
8. While pulling down on the handguard against the lower handguard tang, install and tighten the rear set screw so it just makes contact with the magazine tube. **DO NOT TORQUE THIS SCREW!**
9. Torque front screws to 20-inch lbs. Torque brass set screws to 5-inch lbs.
10. This handguard includes some special nuts that are for the top 45degree slots. Some rifles may need these due to large barrels.
11. Thank you for your purchase.