



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

[www.midwestindustriesinc.com](http://www.midwestindustriesinc.com)

## Ruger PC9 QD Spacer Plate Installation Instructions

Please read all instructions step-by-step before proceeding to install the handguard.

(If instructions are not followed, your warranty is void. If you are not comfortable with this install please have the handguard installed by a qualified gunsmith.)

**Before proceeding, make sure your rifle is pointed in a safe direction, magazine removed and chamber empty. Remove all ammunition and magazines from the workspace.**

- 1.) Lock the action to the rear and face the muzzle away from you.
- 2.) Use the 9/64" allen wrench supplied with the rifle and loosen then remove the two recoil pad Screws.
- 3.) Set the screws and recoil pad aside being careful not to lose the screws.
- 4.) Remove the factory spacer and replace it with the Midwest Industries QD spacer plate.
- 5.) Reinstall the two factory recoil pad screws and tighten until the butt plate is tight, then ½ turn more. **DO NOT OVER TIGHTEN OR YOU WILL CRACK THE RECOIL PAD**
- 6.) Perform a function check to make sure the firearm is in good working condition and all parts were reinstalled correctly.

**Modification or alteration to this part (to include custom coatings on the handguard) voids all factory warranties.**



If you have any questions about the install please give us a call at:  
**262-896-6780**