



SIG 516

MI-516M & MI-516MX

Two Piece Extended Free Float M-LOK Handguard Installation Instructions

- 1.) Please make sure your firearm is unloaded and pointed in a safe direction.
- 2.) Remove factory handguards. Refer to your rifles factory instruction manual.
- 3.) Remove the screws from the MI handguard and set the upper (three sided) section onto the rifle.
- 4.) Set the lower section under the upper and start the screws.
- 5.) Align the rail on the upper and tighten the screws. Torque the screws to 35 inch lbs. Do NOT use thread locker of any kind on these screws.

W292S4498 Hill Side Rd. Waukesha, WI 53189
262-896-6780 Fax 262-896-6756
www.midwestindustriesinc.com



SIG 516

MI-516M & MI-516MX

Two Piece Extended Free Float M-LOK Handguard Installation Instructions

- 1.) Please make sure your firearm is unloaded and pointed in a safe direction.
- 2.) Remove factory handguards. Refer to your rifles factory instruction manual.
- 3.) Remove the screws from the MI handguard and set the upper (three sided) section onto the rifle.
- 4.) Set the lower section under the upper and start the screws.
- 5.) Align the rail on the upper and tighten the screws. Torque the screws to 35 inch lbs. Do NOT use thread locker of any kind on these screws.

W292S4498 Hill Side Rd. Waukesha, WI 53189
262-896-6780 Fax 262-896-6756
www.midwestindustriesinc.com