



W292S4498 Hillside Rd. Waukesha, WI 53189

262-896-6780 Fax 262-896-6756

AK Picatinny End Plate Adaptor

It is recommended these parts are installed by a qualified gunsmith. Failure to read and follow these instructions will void the warranty of these parts and may result in damage to your firearm or optics

Instructions (MI-AK-PEPA)

1. Make sure your firearm is unloaded and pointed in a safe direction
2. Remove the factory stock and pistol grip from your firearm
3. Cut the rear tang off your rifle. Ensure it is flush with the rear edge of the receiver. This can be done with a Dremel or saw
4. Slide the end plate adaptor into the receiver of your firearm. If it does not fit, you will need to adjust the width of the end plate adaptor so that it can slide into place.
5. Slide the end plate adaptor in just short of the tension blocks on the side of the PEPA.
6. Install the tension blocks and slide in the part over the beginning of these blocks, leaving the tension screws exposed.
7. Tighten the adjustment screws so the tension blocks make contact with the receiver.
8. Slide the PEPA in the rest of the way until it makes contact with the receiver. This may need tapping from a rubber mallet to seat properly.
9. Install the provided flat head screw
10. Reinstall your pistol grip and all other parts of your firearm.

Instructions MI-AK-PEPA-M70

Fitting may be required

1. Make sure your firearm is unloaded and pointed in a safe direction
2. Remove your factory stock
3. Install the MI railed end plate with provided lock washer and bolt
4. Reassemble Rifle

Instructions MI-AK-PEPA-4.5MM / MI-AK-PEPA-5.5MM

Fitting may be required

1. Make sure your firearm is unloaded and pointed in a safe direction
2. Remove the pivot pin on your rifles' factory stock and remove the stock
3. Install the MI railed end plate into the rifles trunnion
4. Re-install the stock pivot pin

Installation Video ---

